

King Headz, Inc.
KP-276 CVD Pin Keeper
Instructions

- (1) Remove the drive shaft.
- (2) Remove the stock set screw completely (not needed now)
- (3) Before installing shaft back on the vehicle, install the new set screw below flush.
- (4) Slide the aluminum Pin Keeper onto the hub and line up the set screw with the hole.
- (5) Remove the setscrew (this will make sure the screw fits correctly without causing any cross threading.
- (6) Install the drive shaft onto the vehicle and install the set screw using Blue Loctite.
- (7) Install the boot.

It is highly recommended at this time to do any greasing/ maintenance to the pins.