



King Headz  
MBX6-020  
Adjustable Toe-In Plate


Install the bushing  
from the outside of the plate.



1° Anti-Squat - 2.5° Toe In



1° Anti-Squat - 2.75° Toe In




1° Anti-Squat - 3.0° Toe In




PRINT ON BOTH SIDES

King Headz  
MBX6-020  
Adjustable Toe-In Plate


Install the bushing  
from the outside of the plate.



0° Anti-Squat - 2.5° Toe In



0° Anti-Squat - 2.75° Toe In



0° Anti-Squat - 3.0° Toe In

